



# Generation II™ Timer



SONCELL NORTH AMERICA  
A PUBLIC SAFETY COMPANY

## INSTRUCTIONS

REV. 1-3-23

**\*\*\*SUPPLEMENTAL INSTRUCTION SHEET FOR RETROFITTING NEWER, SIX PIN TIMERS TO OLDER FIVE PIN FUSE BLOCKS\*\*\***

### COMPATIBILITY

We have ceased production of five terminal timers. The newer six terminal timer has been designed to be backwards compatible with the original five terminal timer fuse panels for service replacement purposes.

### TIMER MODIFICATION

In order to use the six terminal timer on a five pin fuse panel, the unused sixth terminal must simply be removed. This is best accomplished by cutting the unused terminal with flush cutting wire cutters, generally referred to as "flush cutters" by technicians. Cutting the terminal is straightforward, but it must be done carefully. The terminal that must be removed is marked "J7" on the circuit board, but it's also a good practice to look at both timers simultaneously to verify you're removing the correct terminal. Refer to diagrams at right.

